


LEUCHTEK®

LED SCOOP DOWNLIGHT USER GUIDE

Series PS



LED SCOOP DOWNLIGHT USER GUIDE


■ Important Safety Instructions:

Basic safety precautions should always be followed when installing, including the following:

1. Read all instructions.
2. Licensed electrician for installation only.
3. Always ensure the power is OFF and the fitting has cooled down before performing any maintenance, cleaning, changing the globe or adjustment to the fitting.
4. Do not install any luminaire near the heat source.
5. Do not exceed the nominal supply voltage or amperage ratings.
6. To avoid injury or damage to the fitting, please ensure that power leads and screws are secure before connecting the power.
7. The light source contained in this luminaire shall only be replaced by a qualified person.
8. The external flexible cable or cord of this luminaire cannot be replaced; if the cord is damaged, the luminaire shall be destroyed.
9. Installation may require advice from a qualified person.
10. The luminaires are not suitable for covering with thermally insulated material.

■ Installation Instruction

Fig 1: Installation Spacing



Tab 1: Ceiling cutout reference table.

Downlight dia (inch)	2.5	4	6
Ceiling Cutout (mm)	85-90	120-130	160-170

NOTE: Before installation, please check the IP label on the luminaire to choose the right place to install.

IP20/IP40	Indoor use only, do not use in wet or damp place.
IP44/IP54	Suitable for indoor areas including bathrooms and covered/sheltered areas such as porches.
IP65	Suitable for outdoor areas, not suitable for water immersion.

NOTE: Before installation, please check the information of driver as below.

Non-dim	Can not be used with any dimmer.
Triac dim	Compliable with recommended TRIAC dimmers, dimming range 8-100%.
0/1-10V	Only work with 0/1-10V dimming system, dimming range 8-100%.
DALI	Only work with DALI dimming system, dimming range 8-100%.


■ Installation Procedure

WARNING ⚡


1. Switch off before installation.
2. Switch on only after complete installation and examination of the circuit.
3. Professional electrician for installation and maintenance only.




Turn Off power supply before starting any installation. Read instructions & check you have all the tools & accessories to complete the installation correctly.




1. Open a hole according to the cutout size of led downlight.



2. Use screw-driver to open the driver terminal cover, feed the main AC wire L, N in terminal block respectively, then fix the cover back.



3. Pull the fixture down before fixing to the ceiling. Connect the downlight with driver, hold back the spring clip then push the downlight into the hole.



4. Make sure the downlight fixed tightly in ceiling, turn on the power (Fig 1).

LEUCHTEK®

LEUCHTEK GmbH

Am Hopfenbach 12, 22926 Ahrensburg, Deutschland
www.leuchte.de | Tel.: +49 4102 7798707 | info@leuchte.de